

398-9001

thepark and facilities

1-866-280-9894 www.thepar

6/30/2015 Page 1 of 8



3350 NW Boca Raton Blvd., Suite B2 Boca Raton, FL, 33431 1-866-280-9894

### **WARRANTY & TERMS**

**WARRANTY: 5 Year Limited Warranty on Thermoplastic coated elements.** The Park and Facilities Catalog guarantees all items for one full year to be free of defects in workmanship or materials when installed and maintained properly. We agree to repair or replace, any items determined to be defective. Items specifically not covered by this warranty include vandalism, man made or natural disasters, lack of maintenance, normal weathering or wear and tear due to public abuse.

Damages or loss in transit is the responsibility of the carrier, whether visible or concealed. It is the responsibility of the recipient to assure that the order is received complete. Before signing the delivery receipt, inspect the shipment immediately and completely. Note any damages or shortages on the bill of lading. Damage reports must be filed within 10 days. The Park and Facilities Catalog is NOT responsible for damages or loss in transit. Title to all goods passes to the customer at the time of shipment. The Park and Facilities Catalog will assist in filing claims if the freight arrangements were made by The Park and Facilities Catalog at your request.

**CANCELLATIONS AND RETURNS:** Cancellations are only accepted with approval of The Park and Facilities Catalog. No merchandise shall be returned without a Return Goods Authorization number which is issued by customer service. Any authorized merchandise must be carefully packed and received in saleable condition. A restocking charge of up to 25% will be applied to all returned goods when the error is not the fault of The Park and Facilities Catalog. All returns must be shipped freight prepaid.



www.theparkcatalog.com

1-866-280-9894

6/30/2015 Page 2 of 8




### **SAFETY WARNINGS & EQUIPMENT INSPECTION**

- Owners and installers please note these safety warnings and make use of this checklist on a regular basis.
- Follow installation instructions when erecting equipment.
- Ground surfaces around equipment should be restored as needed. Concrete footings should never be exposed. Surface depth should comply with ASTM and CPSC specifications.
- Check for and repair damage caused by wear or vandalism, a major factor in injury causing situations.
- All protruding bolts should be covered or cut off and finished smooth. Sharp edges on pipes should be capped or removed. Check for bent, broken, or severly worn pipe, and replace.
- All equipment should be free of rust and repainted whenever necessary to deter rusting.
- We provide our customers with layout sheets and installation instructions. Please keep on file the specifications sheet that contains the listing of every part used.
- Never add components not intended for use with this product.
- Regular maintenance is necessary in this and all park and recreational equipment to insure the safety of the user.
- Note: Proper maintenance of equipment requires regular tightening of all bolts, nuts, and setscrews.
- Note: Regular checking of all parts, castings, etc. should be made. If a part is broken or worn, it should be replaced immediatly.
- Check to be sure all fittings are tight and that bars and pipes do not move.
- Replace all worn S-hooks. S-hooks must be completely closed. Failure to close S-hooks can result in serious injury to the user.
   NEVER reuse S-hooks.
- Test for free movement of swing hanger and other moving attached parts.
- Check for worn chains and replace them.
- A soft resilient surface should be placed under all swings extending at least twice the height of the top rail both front and back.

thepark and facilities


www.theparkcatalog.com


6/30/2015 Page 3 of 8





6/30/2015 Page 4 of 8

## TOOLS REQUIRED









thepark and facilities

1-866-280-9894

www.theparkcatalog.com

6/30/2015 Page 5 of 8

### THE PARK AND FACILITIES CATALOG PRODUCT SPECIFICATIONS

# 43SM-S6 KENSINGTON BENCH WITH BACK

Seats: Seats dimensions are 72-3/4" x 24-1/4" x 21-1/4". Slats are 1-1/2" x 1/4" flat steel strips precision formed. Seat attachment plates are made of 3" x 3/8" flat steel. Reinforced with 1-5/16" steel tube and 5/8" steel rod. Electrically MIG welded.

Frame: Legs are 2-7/8" x 12 Gauge steel tube. Seat Mounting Plates are made of 3" x 1/4" flat steel. Surface Mount Plates are 8" square x1/4" thick flat steel plate. Electrically MIG welded.

Seat & Frame Coating: Steel is sandblasted to near white condition. Coated with zinc rich epoxy primer and top coated with electrostatic powdercoat, oven cured.


Hardware: All stainless steel hardware fasteners.


Dimensions: 6' surface mount bench with back. Seats are 24" wide x 72.5" long. Seat height is 18" from the ground to the top of the seat. The overall dimensions are 72.5" x 24" x 36-1/4".

thepark AND FACILITIES

www.theparkcatalog.com

### **COMPONENTS**





ITEM NO.	PartNo	DESCRIPTION	Qty.		
1	01-01-0504	Kensington w/back Slat Seat 6'	1		
2	01-01-0507	Kensington w/ back SM Leg	2		
3	33-05-0049	3/8" x 1 1/2" Machine Bolt (SS)	4		
4	33-02-0008	3/8" Flat Washer (SS)	8		
5	33-03-0013	3/8" Kep Nut (SS)	4		


Recommended Surface Mount Hardware: 3/8" x 3-1/2" Concrete Expansion Anchor Bolts (Not Included)

thepark and facilities

1-866-280-9894

www. the park catalog. com

6/30/2015 Page 7 of 8



6/30/2015 Page 8 of 8





398-9001

thepark and facilities

1-866-280-9894

www.theparkcatalog.com

4/8/2015 Page 1 of 9



### **SAFETY WARNINGS & EQUIPMENT INSPECTION**


- Owners and installers please note these safety warnings and make use of this checklist on a regular basis.
- Follow installation instructions when erecting equipment.
- Ground surfaces around equipment should be restored as needed. Concrete footings should never be exposed. Surface depth should comply with ASTM and CPSC specifications.
- Check for and repair damage caused by wear or vandalism, a major factor in injury causing situations.
- All protruding bolts should be covered or cut off and finished smooth. Sharp edges on pipes should be capped or removed. Check for bent, broken, or severly worn pipe, and replace.
- All equipment should be free of rust and repainted whenever necessary to deter rusting.
- We provide our customers with layout sheets and installation instructions. Please keep on file the specifications sheet that contains the listing of every part used.
- Never add components not intended for use with this product.
- Regular maintenance is necessary in this and all park and recreational equipment to insure the safety of the user.
- Note: Proper maintenance of equipment requires regular tightening of all bolts, nuts, and setscrews.
- Note: Regular checking of all parts, castings, etc. should be made. If a part is broken or worn, it should be replaced immediatly.
- Check to be sure all fittings are tight and that bars and pipes do not move.
- Replace all worn S-hooks. S-hooks must be completely closed. Failure to close S-hooks can result in serious injury to the user.
   NEVER reuse S-hooks.
- Test for free movement of swing hanger and other moving attached parts.
- Check for worn chains and replace them.
- A soft resilient surface should be placed under all swings extending at least twice the height of the top rail both front and back.

1-866-280-9894

thepark and facilities


www.theparkcatalog.com


4/8/2015 Page 3 of 9





4/8/2015 Page 4 of 9

## TOOLS REQUIRED









theparkand facilities

1-866-280-9894

www.theparkcatalog.com

4/8/2015 Page 5 of 9

### THE PARK AND FACILITIES CATALOG PRODUCT SPECIFICATIONS

# 43S-S6 KENSINGTON BENCH WITH BACK

Seats: Seats dimensions are 72-3/4" x 24-1/4" x 21-1/4". Slats are 1-1/2" x 1/4" flat steel strips precision formed. Seat attachment plates are made of 3" x 3/8" flat steel. Reinforced with 1-5/16" steel tube and 5/8" steel rod. Electrically MIG welded.

Frame: Legs are 2-7/8" x 12 Gauge steel tube. Seat Mounting Plates are made of 3" x 1/4" flat steel. Electrically MIG welded.

Seat & Frame Coating: Steel is sandblasted to near white condition. Coated with zinc rich epoxy primer and top coated with electrostatic powdercoat, oven cured.

Hardware: All stainless steel hardware fasteners.


Dimensions: 6' in-ground bench with back. Seats are 24" wide x 72.5" long. Seat height is 18" from the ground to the top of the seat. The overall dimensions are 72.5" x 24" x 36-1/4".

thepark and facilities

www.theparkcatalog.com

### COMPONENTS

Attach the 6' Kensington Seat to the Kensington Legs using the specified hardware.




ITEM NO.	PartNo	DESCRIPTION	Qty.
1	01-01-0504	Kensington w/back Slat Seat 6'	1
2	01-01-0595	Kensington w/ back S Leg	2
3	33-05-0049	3/8" x 1 1/2" Machine Bolt (SS)	4
4	33-02-0008	3/8" Flat Washer (SS)	8
5	33-03-0012	5/16" Kep Nut (SS)	4


1-866-280-9894

www.theparkcatalog.com

4/8/2015 Page 7 of 9




4/8/2015 Page 8 of 9



4/8/2015 Page 9 of 9





398-9001



1-866-280-9894

www. the park catalog. com



### **SAFETY WARNINGS & EQUIPMENT INSPECTION**

- Owners and installers please note these safety warnings and make use of this checklist on a regular basis.
- Follow installation instructions when erecting equipment.
- Ground surfaces around equipment should be restored as needed. Concrete footings should never be exposed. Surface depth should comply with ASTM and CPSC specifications.
- Check for and repair damage caused by wear or vandalism, a major factor in injury causing situations.
- All protruding bolts should be covered or cut off and finished smooth. Sharp edges on pipes should be capped or removed. Check for bent, broken, or severly worn pipe, and replace.
- All equipment should be free of rust and repainted whenever necessary to deter rusting.
- We provide our customers with layout sheets and installation instructions. Please keep on file the specifications sheet that contains the listing of every part used.
- Never add components not intended for use with this product.
- Regular maintenance is necessary in this and all park and recreational equipment to insure the safety of the user.
- Note: Proper maintenance of equipment requires regular tightening of all bolts, nuts, and setscrews.
- Note: Regular checking of all parts, castings, etc. should be made. If a part is broken or worn, it should be replaced immediatly.
- Check to be sure all fittings are tight and that bars and pipes do not move.
- Replace all worn S-hooks. S-hooks must be completely closed. Failure to close S-hooks can result in serious injury to the user.
   NEVER reuse S-hooks.
- Test for free movement of swing hanger and other moving attached parts.
- Check for worn chains and replace them.
- A soft resilient surface should be placed under all swings extending at least twice the height of the top rail both front and back.

thepark and facilities


www.theparkcatalog.com


4/8/2015 Page 3 of 8


# **HARDWARE** 3/8 x 1-1/4" Carraige Bolt 3/8" Washer 3/8" Kep Nut thepark AND FACILITIES www.theparkcatalog.com 1-866-280-9894


4/8/2015 Page 4 of 8

## TOOLS REQUIRED









thepark and facilities

1-866-280-9894

www.theparkcatalog.com

4/8/2015 Page 5 of 8

### THE PARK AND FACILITIES CATALOG PRODUCT SPECIFICATIONS

# 44SM-S6 KENSINGTON BENCH WITHOUT BACK

Seats: Seats dimensions are 72-3/4" x 15" x 4". Slats are 1-1/2" x 1/4" flat steel strips precision formed. Seat attachment plates are made of 3" x 3/8" flat steel. Reinforced with 1" sch 40 steel tube and 5/8" steel rod. Electrically MIG welded.

Frame: Legs are 2-7/8" x 12 Gauge steel tube. Seat Mounting Plates are made of 3" x 1/4" flat steel. Surface Mount Plates are 8" square x 1/4" thick flat steel plate. Electrically MIG welded.

Seat & Frame Coating: Steel is sandblasted to near white condition. Coated with zinc rich epoxy primer and top coated with electrostatic powdercoat, oven cured.

Hardware: All stainless steel hardware fasteners.

Dimensions: 6' surface mount bench without back. Seats are 15" wide x 72" long. Seat height is 18" from the ground to the top of the seat. The overall dimensions are 72-3/4" x 15" x 18-1/2".


thepark the facilities

www.theparkcatalog.com

1-866-280-9894

### COMPONENTS

Attach the 6' Kensington Seat to the Kensington Legs using the specified hardware.



ITEM NO.	PartNo	DESCRIPTION	Qty.
1	01-01-0511	Kensington w/o back Slat Seat 6'	1
2	01-01-0507	Kensington w/ back SM Leg	2
3	33-06-0062	3/8" x 1-1/4" Carrige Bolt (SS)	4
4	33-02-0008	3/8" Flat Washer (SS)	4
5	33-03-0013	3/8" Kep Nut (SS)	4


Recommended Surface Mount Hardware: 3/8" x 3-1/2" Concrete Expansion Anchor Bolts (Not Included)

thepark and facilities

1-866-280-9894

www.theparkcatalog.com

4/8/2015 Page 7 of 8



4/8/2015 Page 8 of 8





398-9001



1-866-280-9894 www.the

www.theparkcatalog.com

4/8/2015 Page 1 of 9



### **SAFETY WARNINGS & EQUIPMENT INSPECTION**

- Owners and installers please note these safety warnings and make use of this checklist on a regular basis.
- Follow installation instructions when erecting equipment.
- Ground surfaces around equipment should be restored as needed. Concrete footings should never be exposed. Surface depth should comply with ASTM and CPSC specifications.
- Check for and repair damage caused by wear or vandalism, a major factor in injury causing situations.
- All protruding bolts should be covered or cut off and finished smooth. Sharp edges on pipes should be capped or removed. Check for bent, broken, or severly worn pipe, and replace.
- All equipment should be free of rust and repainted whenever necessary to deter rusting.
- We provide our customers with layout sheets and installation instructions. Please keep on file the specifications sheet that contains the listing of every part used.
- Never add components not intended for use with this product.
- Regular maintenance is necessary in this and all park and recreational equipment to insure the safety of the user.
- Note: Proper maintenance of equipment requires regular tightening of all bolts, nuts, and setscrews.
- Note: Regular checking of all parts, castings, etc. should be made. If a part is broken or worn, it should be replaced immediatly.
- Check to be sure all fittings are tight and that bars and pipes do not move.
- Replace all worn S-hooks. S-hooks must be completely closed. Failure to close S-hooks can result in serious injury to the user.
   NEVER reuse S-hooks.
- Test for free movement of swing hanger and other moving attached parts.
- Check for worn chains and replace them.
- A soft resilient surface should be placed under all swings extending at least twice the height of the top rail both front and back.

1-866-280-9894

thepark and facilities


www.theparkcatalog.com


4/8/2015 Page 3 of 9


# **HARDWARE** 3/8 x 1-1/4" Carraige Bolt 3/8" Washer 3/8" Kep Nut thepark AND FACILITIES www.theparkcatalog.com 1-866-280-9894


4/8/2015 Page 4 of 9

## TOOLS REQUIRED









thepark and facilities

1-866-280-9894

www.theparkcatalog.com

4/8/2015 Page 5 of 9

### THE PARK AND FACILITIES CATALOG PRODUCT SPECIFICATIONS

# 44S-S6 KENSINGTON BENCH WITHOUT BACK

Seats: Seats dimensions are 72-3/4" x 15" x 4". Slats are 1-1/2" x 1/4" flat steel strips precision formed. Seat attachment plates are made of 3" x 3/8" flat steel. Reinforced with 1" sch 40 steel tube and 5/8" steel rod. Electrically MIG welded.

Frame: Legs are 2-7/8" x 12 Gauge steel tube. Seat Mounting Plates are made of 3" x 1/4" flat steel. Electrically MIG welded.

Seat & Frame Coating: Steel is sandblasted to near white condition. Coated with zinc rich epoxy primer and top coated with electrostatic powdercoat, oven cured.

Hardware: All stainless steel hardware fasteners.

Dimensions: 6' in-ground mount bench without back. Seats are 15" wide x 72" long. Seat height is 18" from the ground to the top of the seat. The overall dimensions are 72-3/4" x 15" x 35-3/8".


thepark and facilities

www.theparkcatalog.com

1-866-280-9894

### COMPONENTS


Attach the 6' Kensington Seat to the Kensington Legs using the specified hardware.




ITEM NO.	PartNo	DESCRIPTION	Qty.
1	01-01-0511	Kensington w/o back Slat Seat 6'	1
2	01-01-0595	Kensington w/ back S Leg	2
3	33-06-0062	3/8" x 1-1/4" Carrige Bolt (SS)	4
4	33-02-0008	3/8" Flat Washer (SS)	4
5	33-03-0013	3/8" Kep Nut (SS)	4

1-866-280-9894

www.theparkcatalog.com



4/8/2015 Page 8 of 9



4/8/2015 Page 9 of 9